
ENCELIUM WIRELESS AREA LIGHTING CONTROLLER (WALC) - WIRE TABLE

NOT USED WIRES CAP OFF WIRE END WITH UL LISTED WIRE NUT.

BLACK	LINE (IN) - RELAY CONTACT
RED	LINE (DUT) - RELAY CONTACT (SWITCHED HDT)
WHITE	NEUTRAL
VIOLET	NOT USED - CAP OFF PER CODE
GREY	NOT USED - CAP OFF PER CODE



NOTES:

- 1. REFER TO MANUFACTURER'S SPECIFICATIONS FOR LOAD LIMITS AND DETAILED INSTALLATION INSTRUCTIONS.
- 2. WIRE UNIT IN ACCORDANCE WITH ALL APPLICABLE ELECTRICAL AND BUILDING CODES.
- 3, REFER TO ENCELIUM WIRELESS AREA LIGHTING CONTROLLER INSTALLATION AND SERVICE MANUAL BEFORE INSTALLING OR SERVICING MODULE.
- 4. FOR COMPATIBILITY WITH OTHER CONFIGURATIONS OR DRIVERS/BALLASTS ON ENCELIUM PRODUCTS CONTACT YOUR REPRESENTATIVE.
- 5. FOR SOME INSTALLATIONS, A JUNCTION BOX MAY BE REQUIRED. IT IS RECOMMENDED TO SECURELY MOUNT THE WALC TO THE JUNCTION BOX USING AN AVAILABLE 1/2 INCH KNOCK-OUT

